

IR3-1 BATTERY INSTALLATION INSTRUCTIONS

INSTRUCTIONS D'INSTALLATION DES PILES DE MODÈLE IR3-1

! WARNING !


ENSURE THE UNIT IS COMPLETELY COOL BEFORE STARTING INSTALLATION.
TO AVOID DANGER OF SUFFOCATION KEEP THE PACKAGING BAG AWAY FROM BABIES AND CHILDREN. DO NOT USE IN CRIBS, BED, CARRIAGES OR PLAY PENS. THIS BAG IS NOT A TOY. KNOT BEFORE THROWING AWAY.

! AVERTISSEMENT !

ASSUREZ-VOUS QUE L'APPAREIL EST COMPLÈTEMENT REFROIDI AVANT DE COMMENCER L'INSTALLATION. AFIN D'ÉVITER LES RISQUES DE SUFFOCATION, GARDEZ LE SAC D'EMBALLAGE LOIN DES BÉBÉS ET DES JEUNES ENFANTS. NE LE LAISSEZ PAS TRAÎNER DANS LES BERCEAUX, LES LITS, LES POUSETTES OU LES PARCS DE JEU. CE SAC N'EST PAS UN JOUET. NOUEZ-LE AVANT DE LE JETER.

- Install four "AA" batteries into the battery pack. The battery pack is located in the bottom right corner of the appliance. The door may have to be removed to access the battery pack, release the top door latches then tilt the door forward and lift from slots.
- Install one "9V" battery into the remote transmitter.
- Replacing the batteries in the remote transmitter and battery pack should be done on a yearly basis. (Frequent beeping for 3 seconds when the appliance turns on indicates low battery on the remote receiver, replace the batteries in the battery pack. The "LOW BATTERY INDICATOR" will flash in the top right corner of the remote transmitter when batteries need replacing).

NOTE: When low battery occurs the appliance will shut down. We recommend installing high quality batteries to reduce the corrosion and seepage in the components.



- Installez quatre « AA » piles dans le bloc-piles. Le bloc-piles est situé dans le coin inférieur droit de l'appareil. La porte principale doit être enlevée pour accéder aux piles, déverrouillez les deux loquets supérieurs puis penchez légèrement vers l'avant et soulevez hors des fentes.
- Installez une « 9V » pile dans la télécommande.
- Nous vous recommandons de remplacer les piles chaque année. (Des bips répétitifs pendant 3 secondes lorsque l'appareil se met en marche indiquent que les piles du récepteur sont faibles, remplacer les piles du bloc-piles. L'indicateur de « L'ALARME DE PILE FAIBLE » est située dans le coin supérieur droit de la télécommande, remplacer les piles quand l'indicateur clignote).

REMARQUE: Lorsque les piles sont faibles, l'appareil s'éteint. Nous recommandons d'installer les piles d'haute qualité pour réduire la corrosion et infiltration dans les composants.

TO VIEW A VIDEO OF THIS INSTALLATION VISIT OUR WEBSITE AT: www.napoleonfireplaces.com/productsupport/ir3-1/

NOTE: FOR MORE DETAILED INSTRUCTIONS REFER TO YOUR INSTALLATION MANUAL.

POUR REGARDER UNE VIDÉO DE CETTE INSTALLATION VISITER NOTRE SITE WEB: www.napoleonfireplaces.com/productsupport/ir3-1/

NOTE: VOIR LE MANUEL D'INSTRUCTIONS D'INSTALLATION POUR LES INSTRUCTIONS PLUS DÉTAILLÉES



Quality System Certified To
ISO
9001-2008
11.13.13